

Fall 1993

INTERNATIONAL NEWSLETTER FOR SHOT PEENING-SURFACE FINISHING INDUSTRY

IN THIS ISSUE

Loads Page 1

Shot Peening Workshop

Shot Peening For Carburized

Steel Page 6

Impact Peening ... Page 20

Tosoh Corporation

The Shot Tower

Jack Champaigne Page 25

Letters To The Editor

. Page 26

Systems Page 27

Excerpt from Bambi

Available Page 31

.... Page 30

.... Page 22

Shot Peening Process Variables Page 16

News Release

News Release

From the Desk of

News Release

Friess Abrasive Blast

Application Notes

Vacu-Blast Limited/

Gearing Up For Higher

GEARING UP FOR HIGHER LOADS

by John S. Eckersley

If only cars could fly..."

Have you noticed that the design philosophy of the car that you drive is approaching the design philosophy for airplanes? No, we don't mean that cars are about to sprout wings and soar above the traffic iams - though there is much that is attractive about that thought! We mean that today's cars are, of necessity, lighter, more compact, more durable, as well as being safer and more reliable and comfortable. Any engineer involved with the dynamic components of a car or truck: the powertrain, steering or suspension, is immediately faced with the dichotomy of designing

smaller parts to carry greater loads. For instance, a transmission engineer has only so much space in which to work under the hood of an aerodynamically efficient front wheel drive vehicle. Then, no sooner does he have a successful transmission than the engine design guys figure out a way to increase the horsepower...

HOW TO INCREASE THE **FATIGUE STRENGTH OF** GEARS BY 20% TO 50%.

ISSN 1069-2010

1993123

If you think the problem is limited to passenger vehicles, take a closer look at the huge trucks that go hurtling past you: speed is obviously a selling point but so is weight, the less the better. Less truck weight means more payload and it is payload that produces profits. (Doesn't that sound familiar to you aircraft guys?) Under present day conditions of extended warranties, design criteria on materials very quickly pass from ultimate or yield strengths to fatigue limits.

Let's continue with the example of transmissions, since we all drive cars. Each tooth on a transmission gear can be thought of as a cantilevered beam that is deflected each time it engages with the corresponding dear or pinion.¹ After (hopefully) many millions of cycles, a tiny crack can



eventually appear in the root of a gear tooth, which is the area that carries the greatest load (actually, the tooth root is the fulcrum of the cantilevered beam). How many millions of cycles the tooth will last without cracking defines the fatigue life. How much load (stress) defines the fatigue strength or endurance limit. It doesn't take much to figure out that as the load increases, the life decreases. Fatigue life is usually plotted as an "S/N" curve: "S" for stress and "N" for number of cycles to failure (Figure 1).² By definition, the fatigue strength or endurance limit is the stress level below which the part will have "infinite life", a term which, like beauty, is in the eye of the beholder. A designer of a gear that is used in a drill for the home market may consider "infinite life" to be ten million cycles; a similar gear for a professional tool may need to run for 100 million cycles.

0

Returning to the transmission engineer who is faced with a higher horsepower engine: he may soon discover that one or two of his gears, or a shaft, for instance, start to break at less than "infinite life", as the load/stress goes up. What are his options? Not too many:

- 1. He can consider a larger gear. That certainly would reduce the load on each tooth, but this is hardly an option. A larger gear would almost certainly mean a larger transmission which would no longer fit the design envelope but would also involve a very costly retooling.
- He can increase the strength of the material, if he 2. is not already at the limit. Mostly, transmission gears are of carburized steel and case hardened to 60 HRC minimum and, for practical purposes, that is about as strong as you can get. Aircraft quality gears, for helicopter and turbo-prop transmission, for instance, and some marine gears, can be made stronger but are cost-prohibitive for most landbased applications. There is another problem, though: in many cases, steel becomes increasingly brittle or notch sensitive as hardness is increased. In other words, beyond a certain strength level, as the ultimate tensile strength goes up, the fatigue strength goes down. There is a rather simple way to overcome this phenomenon and we will address it later in this report.
- 3. The transmission designer can change the surface stress pattern in the gears. This option takes some explanation but it may offer the ideal solution to the problem of "higher horsepower". Changing the stress pattern does not reduce the load, but it can increase the fatigue strength by 20-30%, often more. It requires no change of material, nor does it increase the size or weight of the gear. Best of all, it is very cost effective.

HOW TO PREVENT FATIGUE CRACKS

Let's go back to thinking of a gear tooth as a cantilevered beam. When the tooth is engaged, the operating load causes a tensile stress or a stretching action of the steel in the root radius on the load side. On the opposite side, the root radius is being pushed together in a compressive stress. It is easy enough to see that, after many load cycles, fatigue cracks can start only where the metal is being stretched the most in tension; fatigue cracks can never start where the metal is being pushed together in compression. The trick, then, is to find a way to pre-load the tension side of the root with a compressive stress that must be overcome by the applied load before any fatigue crack can start. This will raise the fatigue strength and allow an increase in load (stress) for the same life (cycles) or a longer life (more cycles) at the same load. We have been using gears as our example, but the same principle is true for springs, crankshafts, connecting rods, ball studs, jet engine components, wing structures, highway bridges, crane booms - any metal component that experiences

repeated service loads, The most practical and economical process to generate the high magnitude of residual compressive stresses in such a wide variety of parts and geometries is Controlled Shot Peening.³

WHY SHOT PEENING WORKS

Shot peening involves the bombardment of the metal part by millions of tiny (typically .023 inch or 0.5 mm diameter) steel spheres, each of which slightly indents the surface upon impact. Sometimes, the peening media may be glass or even ceramic beads. Shot peening is often called "mechanical or impact prestressing" and under each indentation, there is formed a hemisphere of cold-worked metal that tires to push the indentation out again and restore the surface to its original shape. Because the surface has been yielded (in tension) past its elastic limit, the indentation remains and the cold-worked hemisphere develops a compressive self-stress (or residual stress) that is beneath the surface, to a depth of typically 0.020 inch or 0.50 mm. The value of the self-stress is just below the yield strength of the metal: if it were greater than yield, it would push the dimple out and if it were less than yield, the dimple would remain deeper; in short, an equilibrium is reached just below yield.4

This very high magnitude of compressive prestress must be overcome by the applied load before a fatigue crack can start at the surface. Since applied loads rarely exceed the yield strength, the endurance limit and/or life is greatly increased for that particular part. In our example, the transmission gears and shafts in question can be shot peened very economically and will now sustain the higher horsepower without any other change in the transmission design. Actually, controlled shot peening is often included at the design stage to produce a lighter transmission in the first place, particularly for aerospace applications (Figure 2).⁵



OVERCOMING DETRIMENTAL MANUFACTURING EFFECTS

The irony is that many of the most common manufacturing processes used to make metal parts actually have the effect *Continued on Page 8.....*

Gearing Up For Higher Loads Continued from Page 2

of dramatically lowering the fatigue strength - a fact that is often not well understood by design engineers. It is reasonable to assume that if a part is dimensionally correct and the material is to specification, all is as it should be. However, residual stresses left over from grinding, for instance, can lead to premature failures (See Figure 3).⁶



Manufacturing processes detrimental to fatigue are not limited to grinding. On the list are through-hardening to very hard hardness levels (as opposed to surface hardening, which is beneficial), abusive machining, hard plating, anodizing and flame coating, welding, even electrodischarge machining and electro-chemical milling. If you want more information on these, please order "Shot Peening Applications" from Metal Improvement. We will comment, though, on through hardening, as it has application in gearing. Most metals, as you increase their hardness level, after a point become increasingly brittle or notch-sensitive. With steels, the fatigue strength typically begins to fall off as the hardness passes about 40 HRC (See Figure 4) - the brittle metal simply cracks more easily. However, if the steel is shot peened, the fatigue strength increases proportionately to the hardness. Using the example of Figure 4, the SAE 4340 aircraft quality steel actually exhibits almost three times the fatigue strength, in the shot peened samples, at an ultimate tensile strength of 300 KSI. This principle is often employed on the gears, hammers and anvils of impact tools that are subject to very high shock loads and wear. It is also used for aircraft landing gears and propeller hubs where very high strengths are used so as to be able to reduce weight.



Fig 4: COMPARISON OF PEENED AND UNPEENED FATIGUE LIMITS FOR SMOOTH AND NOTCHED SPECIMENS AS A FUNCTION OF ULTIMATE TENSILE STRENGTH OF STEEL

RECENT DEVELOPMENTS IN SHOT PEENING OF GEARS

By understanding the effects that can be produced by shot peening, a gear designer can derive benefits mainly from the following two advantages:

- a) Improved bending fatigue strength of the gear tooth in the root fillet;
- b) Increased surface fatigue resistance to retard pitch line pitting.

It makes sense and has been well known for many years that for maximum residual compressive stress, the shot hardness should at least equal the hardness of the part. It appears that this practice is gaining popularity, probably because designers are increasing the loads upon components and must squeeze out as much fatigue strength as possible. Figure 5 shows the residual stress distribution on an automotive transfer shaft peened on the hypoid pinion teeth with regular (45-52 HRC) and hard (55-62 HRC) shot.



The teeth are SAE 8620 carburized and hardened to 60-64 HRC, and the hard shot is used in production (MI 230H at 18-22A intensity and 200% coverage, verified by Peenscan®.⁸ It should be noted, however, that a helicopter manufacturer specifies regular hardness shot for peening of their very hard transmission gears: they are willing to forego the extra margin of residual stress gained from hard shot in favor of preserving the surface finish of their near-polished gear faces.

Recent testing, by the University of Munich, was performed on shot peened automotive transmission gears. Alloys were SAE 6120 and an European alloy designated 20 NiMoCrS63, carburized and hardened to 60 HRC minimum. Both sets of gears were peened with MI 170H shot at 10-12A and 200% coverage, verified by Peenscan®, and were processed at MIC's shot peening facility in Unna, Germany. Figure 6 indicates fatigue strength increase of 42%. Also from Europe comes the chart in Figure 7 that shows increased depth and magnitude of compression on a carburized surface as the result of increasing shot velocity.⁹



Fig 6: S/N CURVE FOR CARBURIZED 20N, MoCr 563 GEARS



DUAL INTENSITY SHOT PEENING

If you look again at Figure 7 you will notice that the maximum residual compressive stress is at a depth of between 0.0005 and 0.002 (0.013 and 0.05 mm). At the immediate surface, there is a reduction in the compressive stress. Assuming no detrimental products of transformation

(oxidation) at the surface (more on this later), this decrease in stress at the surface can be restored by a secondary peening with smaller shot at a lower intensity. The surface residual stress in carburized SCM 420 (Japan) steel is increased by dual peening from about 780 MPa to 1330 MPa.¹⁰ Figure 8 shows that the fatigue properties of SCM 420 gears are improved by 50% from dual peening when compared to "as carburized". Dual peening involves peening the part with a shot size and intensity that would be normal for that part and then following up with a secondary peening using a much smaller shot size and correspondingly lower intensity. Dual peening obviously increases the cost of processing but can be well worth it, for instance, for racing car applications or aircraft turboprop gearing, where maximum fatigue strength is paramount.



Fig 8: GEAR FATIGUE PROPERTIES OF SCM420

CARBONITRIDING AND HARD SHOT PEENING

From Japan comes a report of yet another approach to extracting the most from the least; the most fatigue strength from the lease gear size.¹¹ Oddly, Miwa et al apparently initiated their project with the intent of reducing surface roughness caused by peening carburized gears with hard shot. They had observed the relatively softer immediate surface layer caused by products of transformation and often referred to as "zone of decarburization". Because it was softer, this thin surface layer produced a rougher tooth profile surface when it was peened. Certainly, this is a correct observation, but what is surprising is that the researchers were apparently not concerned by the reduction in fatigue strength that is caused by a decarburized laver, however thin, which can actually be offset by peening.¹² Miwa et al developed a multi-step carbonitriding process to permeate nitrogen into only the extremely shallow surface layer, thereby reducing oxidation and the undesirable products of transformation. They found that peening with hard shot (in this case 53-55 HRC) produced a much higher residual compressive stress (64% more than conventional shot peening) but they also found that they could produce a significant increase in surface hardness. In addition, they

were able to maximize residual compressive stress and micro hardness from what they termed "hard shot peening" when the content of retained austenite was transformed into martensite by the action of the peening. In terms of improvement in fatigue strength, their new carbonitriding process followed by their hard shot peening, produced an increase of 1.3 times the fatigue strength of standard carburizing followed by peening with regular hardness (46-48 HRC) shot, (Figure 9).



Fig 9: ROTATING BENDING FATIGUE STRENGTH OBTAINED BY CARONITRIDING AND HARD SHOT PEENING

SHOT PEENING "ALLOWABLES"

From the foregoing, we have seen results of testing showing improvements in bending fatigue strength of carburized and shot peened gears as high as 42%, when compared to carburized only gears; and 50% from dual peening. This is a far greater effect than can be obtained by any other process, with only insignificant changes to gear geometry. At the same time, controlled shot peening is a very economical process that adds usually less than 5% to the cost of a finished gear or shaft. To take full advantage of the shot peening benefits, it is necessary to conduct fatigue tests for a given gear under at least simulated operating conditions. However, not all gear applications warrant extensive testing and designers look for rules of thumb that they can apply to their gears. Gears are, after springs, the most commonly peened component, from the finest pitch to segmented mining gears 40 feet (12 meters) in diameter. Also, shot peening is beneficial on spur gears, bevels, spiral bevels, hypoids, rings, pinions, internals, racks, even splines. With all this variety, there are still some rules of thumb that apply. American Gear Manufactures Association Standard ANSI/AGMA 2004-B89 states: "Shot Peening...may improve the bending fatigue strength of a gear tooth as much as 25 percent" but warns that "shot peening should not be confused with grit and shot blasting, which are cleaning operations". Lloyd's Register of shipping, in a letter dated 3rd May 1990,

informed Metal Improvement Company that "the following allowance will be considered with the new Gearing Rules where properly controlled shot peening process has been applied to gear teeth. "Surface stress - no increase of the allowable Hertzian contact stresses." "Bending stress - up to a 20% increase of the allowable bending stress at the tooth root". Germanischer Lloyd advises that "If the fatigue bending strength of the teeth is increased by a technique approved by the Society, e.g. by shot peening, then values - by up to 20% for case-hardened tooth systems and by up to 10% for gears made of quenched and tempered steels may be allowed". Det Norske Veritas also allows 20%.

SHOT PEENING RETARDS SURFACE PITTING OR SPALLING

In 1982, work performed at NASA's Lewis Research Center, was published by Townsend and Zaretsky.¹³ This comprehensive report showed that the pitting fatigue life of AISI 9310 (carburized) spur gears was lengthened by 50% when the gear faces were peened at "medium intensity" using MI 70R shot at 7-9A (0.18-0.23mm) with 100% coverage. In 1992, Dennis P. Townsend presented a follow-on paper at the Sixth International Power Transmission and Gearing Conference. The new work involved the same gears and material but a "high intensity" shot peening was used: MI 330H shot at 15-17A (0.38-0.43mm) with 200% coverage.¹⁴ In both cases, Peenscan® was used for coverage determination - also note the use of hard shot in the second series of tests, as well as the additional coverage. In both groups, the gears were honed after shot peening to a 16 RMS surface finish. "The 10 percent surface fatigue (pitting) life of the high intensity shot peened gears was 2.15 times that of the gears that were shot peened to a medium intensity." This very considerable improvement was attributed to 57% higher residual stress at the peak, with greater depth of compression. We have taken the liberty of combining the curves from both papers and present them in Figure 10.





It is interesting to note that the "high intensity" shot peening increased the pitting fatigue life by almost four times when compared to the unpeened test gears.



CONCLUSION

Do all gears require shot peening? Of course not, but the fatique strength of just about all metal gears can be improved by shot peening: even "perfect" gears. There is a school of thought that claims that "perfectly" manufactured gears do not need shot peening. We couldn't agree more, but "perfection" (like beauty, in our earlier example) is a relative term; relative, in the case of a gear to its application. A "perfect" gear guickly becomes less than perfect when it is necessary to increase the load beyond the original design criteria. For many applications, the "perfect" gear must be as small as possible to meet the demands of envelope, weight and fuel economy. Α "perfect" gear may well be one that is sufficient to do the job for the price but is far from the ultimate in terms of material, machining and processing. In all these cases, and many others, intelligent use of controlled shot peening may well be the answer to meeting the demands of the application. Remember that even a modest 10% increase in fatigue strength can result in an increase in gear life by an order of magnitude or more. At Metal Improvement Company, we have the engineering know-how not only to process your gears but to develop, without exhaustive and expensive testing, the parameters that will produce the best results from shot peening. After all, the first parts we ever peened, for our very first customer, were gears, back in 1945. Today, we have 34 shot peening job shops in principal industrial centers of North American and Europe and field crews that can be deployed world-wide. Please let us help you solve your gearing challenges.

REFERENCES

1. Daly, J.J., "Boosting Gear Life Through Shot Peening"; Machine Design, May 12, 1977

2. Loewenthal, S.H., "Design of Power Transmission Shafting"; NASA Report RP-1123

3. "Shot Peening Applications"; 7th Edition, Metal Improvement Company, Inc.

4. Eckersley, J.S., "Shot peening Process Controls Ensure Repeatable Results"; Shot Peening Theory and Applications, A. Niku-Lari, Ed.; I.I.T.T. International

5. Daly, J.J., "A Concept for Using Controlled Shot Peening in Original Gear Design" American Gear Manufactures Association, Technical Paper No. 87FTM13

6. Koster, W.P. et al, "Surface Integrity of Machined Structural Components"; Technical Report AFML-TR-70-11, March 1970

7. Horger, O.J., "Mechanical and Metallurgical Advantages of Shot Peening"; The Iron Age, March 29 and April 5, 1945

8. O'Hara, P., "Dyescan Tracers as a Quality Control Tool for Coverage Determination in Controlled Shot Peening" SAE Technical Paper Series 850708, February 1985

9. Sholtes, B. and Macherauch, E., "Case-Hardened Steels: Microstructural and Residual Stress Effects"; D.E. Diesburg, Ed. TMS-AIME, 1984, pg. 141-151. Referenced by Kraus, G. "Microstructures and Properties of Carburized Steels"; Metals Handbook, Volume 4, Heat Treating, ASM

10. Hatano, A. Namiki, "Applications of Hard Shot Peening to Automotive Transmission Gears"; Daido Steel Co., Ltd.; Steel Res. Section

11. Miwa, Y. et al, "Carbonitriding and Hard Shot Peening for High-Strength Gears"; SAE Technical paper Series 880666

12. "Material Characterization of Aermet 100"; WL/MLSE, Wright Patterson AFB, OH 45433-6533

13. Townsend, D.P. and Zaretsky, E., "Effects of Shot Peening on Surface Fatigue Life of Carburized and Hardened AISI 9310 Spur Gears"; NASA Technical Paper 2047, 1982

14. "Improvement in Surface Fatigue Life of Hardened Gears by High-Intensity Shot Peening"; NASA Technical Memorandum 105678, 1992

Reprinted from Impact, Spring 1993; ©Metal Improvement Company, 10 Forest Avenue, Paramus, New Jersey, 07652

